



# **SE4 & SE8**

## **SHAFT EXTENDER KITS**

### INSTALLATION INSTRUCTIONS



© Copyright 2011, ATI Audio Inc.

## **SE4 & SE8 SHAFT EXTENDER FOR FINGERTIP ADJUSTMENT FOR MULTIPLE AMPLIFIER ARRAY**

Note: Shaft Extender Kits SE4 and SE8 come with a quantity of four or eight shaft extenders, depending on the model ordered.

1. Remove the top cover of the amplifier unit and save the hardware.
2. Locate the "Red" LED on the front panel and pop it out. Be careful not to break the leads.
3. Remove the front panel via 4 screws and save the hardware.
4. Using a long nose plier, pinch the rear of the slotted shaft while pushing the wheel out on each of the pots.
5. Replace the original wheels with the new shaft extenders inserting the slotting end into the pot; the shaft just pops into place.
6. After inserting all of the shaft extenders into the pots, carefully align the front panel so that the shaft extenders protrude through the holes.
7. Attach-the front panel to the chassis by means of the four screws previously removed.
8. Re-insert the "Red" LED into the front panel.
9. Replace the top cover using the hardware previously saved.

## One Year Limited Warranty

ATI warrants this product to be free from defects in materials and workmanship to its original owner for a period of one year from date of purchase. ATI will repair or replace such product or part thereof, which upon inspection by ATI, is found to be defective in materials or workmanship.

The Proper Return Authorization Number must be obtained from ATI in advance of return. Contact ATI at 856-626-3480 or email [sales@atiaudio.com](mailto:sales@atiaudio.com) to receive the number and instructions for return of your unit.

A written statement providing the name, address, daytime telephone number and email address of the original owner, together with receipt from the original purchase, and a brief description of any claimed defects, must accompany all returns. Parts or product for which replacement is made shall become the property of ATI.

The customer shall be responsible for costs of transportation and insurance to the factory of ATI, and shall be required to prepay such costs.

ATI shall use reasonable efforts to repair or replace any product covered by this limited warranty within thirty days of receipt. In the event repair or replacement shall require more than thirty days, ATI shall notify the customer accordingly. ATI reserves the right to replace any product that has been discontinued from its product line with a new product of comparable value and function.

This warranty shall be void in the event a covered product has been damaged, or failure is caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, or lightning, power fluctuations and other incidental or environmental conditions. Further, product malfunction or deterioration due to normal wear is not covered by this warranty.

ATI DISCLAIMS ANY WARRANTIES, EXPRESS OR IMPLIED, WHETHER OF MERCHANTABILITY OF FITNESS FOR A PARTICULAR USE, EXCEPT AS EXPRESSLY SET FORTH HEREIN. THE SOLE OBLIGATION OF ATI UNDER THIS LIMITED WARRANTY SHALL BE TO REPAIR OR REPLACE THE COVERED PRODUCT, IN ACCORDANCE WITH THE TERMS SET FORTH HEREIN. ATI EXPRESSLY DISCLAIMS ANY LOST PROFITS, GENERAL, SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES WHICH MAY RESULT FROM BREACH OF ANY WARRANTY, OR ARISING OUT OF THE USE OR INABILITY TO USE ANY ATI PRODUCT.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitation on how long an implied warranty lasts, so the above limitations and exclusions may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights that vary from state to state.

ATI reserves the right to modify or discontinue, without prior notice to you, any model or style product.

If warranty problems arise, or if you need assistance in using your product contact us.